

Lever Quick Takedown Screw - Henry Lever Quick Takedown Screw - Black Nitride - 357 MAG

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting. Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting.

Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Attributes

- Name: Henry Lever Quick Takedown Screw - Black Nitride - 357 MAG
- Manufacturer: Ranger Point Precision
- Product no.: BRD261093
- Mfr. No.: 147
- Finish: Black Nitride
- Model: Henry
- Delivery weight: 0.5lb
- Shipping height: 150mm
- Shipping width: 200mm
- Shipping length: 25mm

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry](#)
- [English: Safety Instruction Guide for Henry Lever Quick Takedown Screw](#)

Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der Schnellwechselschraube für Hebel Henry. Dieses Produkt wurde entwickelt, um Ihnen das Entfernen und Ersetzen von Hebeln zu erleichtern und gleichzeitig eine gründliche Reinigung zu ermöglichen. Um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen, beachten Sie bitte die folgenden Sicherheitshinweise.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für Ihren spezifischen Henry Modelltyp geeignet ist.
- Verwenden Sie die Schnellwechselschraube nur für den vorgesehenen Zweck.
- Überprüfen Sie regelmäßig die Schraube auf Abnutzung oder Beschädigungen.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Achten Sie beim Umgang mit Werkzeugen und beim Installieren des Produkts auf Ihre Sicherheit.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer Schutzhandschuhe, wenn Sie mit der Schnellwechselschraube arbeiten, um Verletzungen zu vermeiden.
- Verwenden Sie nur die empfohlenen Werkzeuge für die Installation und Entfernung der Schraube.
- Vermeiden Sie übermäßigen Druck beim Anziehen der Schraube, um Beschädigungen zu vermeiden.
- Stellen Sie sicher, dass die Schraube fest sitzt, bevor Sie das Gewehr verwenden.
- Bei Anzeichen von Beschädigung oder Fehlfunktion verwenden Sie das Produkt nicht und wenden sich an den Hersteller.

Anweisungen für Installation und Nutzung

1. Vorbereitung:

- Stellen Sie sicher, dass das Gewehr entladen ist.
- Reinigen Sie den Bereich um die Hebelschraube, um Schmutz und Ablagerungen zu entfernen.

2. Installation:

- Entfernen Sie die originale Hebelschraube mit dem geeigneten Werkzeug.
- Setzen Sie die Schnellwechselschraube in den vorgesehenen Bereich ein.
- Ziehen Sie die Schraube mit dem empfohlenen Drehmoment an, ohne übermäßigen Druck auszuüben.

3. Nutzung:

- Überprüfen Sie regelmäßig die Festigkeit der Schraube während des Gebrauchs.
- Bei Bedarf können Sie die Schraube einfach entfernen und ersetzen.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Metallabfälle.
- Vermeiden Sie die Entsorgung in der Natur oder in öffentlichen Abfallbehältern.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken bezüglich der Sicherheit oder Nutzung Ihres Produkts wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt gekauft haben. Achten Sie darauf, alle relevanten Informationen über das Produkt bereitzuhalten, um eine schnelle und effektive Unterstützung zu erhalten.

Bitte beachten Sie, dass es wichtig ist, regelmäßig die Sicherheitsupdates und Rückrufinformationen zu überprüfen, um sicherzustellen, dass Ihr Produkt sicher verwendet werden kann.

Safety Instruction Guide for Henry Lever Quick Takedown Screw

Introduction

Thank you for choosing the Henry Lever Quick Takedown Screw. This product is designed to enhance the functionality of your Henry leveraction firearm by allowing for easy lever removal and replacement. Please read this safety instruction guide carefully to ensure safe and proper use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms and accessories with care and follow all safety practices.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for wear or damage before use.
- In case of any malfunction or damage, discontinue use immediately and seek professional assistance.
- Report any unsafe products or accidents to local authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Read the firearm's manual and understand its operation before using the quick takedown screw.
- Ensure that the firearm is unloaded before attempting to install or remove the lever.
- Wear appropriate eye protection while working with firearms and accessories.
- Do not force the screw into place; ensure it fits properly to avoid damage.
- Avoid using the product in wet or humid conditions to prevent corrosion.
- Store the product in a dry place when not in use.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including a suitable screwdriver.
- Ensure that your firearm is unloaded and pointed in a safe direction.

2. Removing the Original Lever Screw:

- Locate the original lever screw on your Henry leveraction firearm.
- Using the appropriate screwdriver, carefully remove the original screw by turning it counterclockwise.
- Set the original screw aside in a safe location.

3. Installing the Henry Lever Quick Takedown Screw:

- Take the Henry Lever Quick Takedown Screw and align it with the screw hole.
- Gently insert the screw into the hole and begin turning it clockwise.
- Tighten the screw until it is secure, but do not overtighten as this may cause damage.

4. Testing the Installation:

- Once installed, check the lever for proper movement and ensure that it operates smoothly.
- If the lever does not function correctly, remove the screw and inspect for any issues before reinstalling.

5. Regular Maintenance:

- Periodically check the screw for tightness and inspect for any signs of wear.
- Clean the screw and surrounding area to prevent dirt and debris buildup.

Disposal Instructions

- Dispose of any old screws or parts responsibly, following local regulations for metal recycling.
- Do not dispose of the product in household waste.
- If the product is no longer usable, consider contacting a local recycling facility for proper disposal options.

Contact Information for Further Support

For any questions or concerns regarding the Henry Lever Quick Takedown Screw, please refer to the product packaging or your retailer for contact information. Always ensure that you have access to support for any safety inquiries or productrelated issues.

Thank you for prioritizing safety and responsible use. Enjoy your enhanced shooting experience with the Henry Lever Quick Takedown Screw!