

Lever Quick Takedown Screw - Henry Lever Quick Takedown Screw - Black Nitride - Star

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting. Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting.

Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Attributes

- Name: Henry Lever Quick Takedown Screw - Black Nitride - Star
- Manufacturer: Ranger Point Precision
- Product no.: BRD261094
- Mfr. No.: 148
- Finish: Black Nitride
- Model: Henry
- Delivery weight: 0.5lb
- Shipping height: 150mm
- Shipping width: 200mm
- Shipping length: 25mm

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry](#)
- [English: Safety Instruction Guide for the Henry Lever Quick Takedown Screw](#)

Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Schnellwechselschraube für Hebel Henry. Dieses Produkt wurde entwickelt, um Ihnen eine einfache Handhabung und Reinigung Ihrer Hebel zu ermöglichen. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Verwendung zu gewährleisten und mögliche Risiken zu vermeiden.

Allgemeine Sicherheitshinweise

- Achten Sie darauf, dass die Schnellwechselschraube für Hebel Henry nur für die angegebenen Modelle verwendet wird.
- Überprüfen Sie vor der Verwendung, ob die Schraube in gutem Zustand ist. Beschädigte Teile sollten nicht verwendet werden.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Informieren Sie sich über Rückrufaktionen und Sicherheitswarnungen auf der EU Safety Gate Plattform.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Tragen Sie beim Umgang mit der Schnellwechselschraube geeignete Schutzausrüstung, einschließlich Handschuhe, um Verletzungen zu vermeiden.
- Achten Sie darauf, dass die Schraube sicher und fest sitzt, bevor Sie den Hebel verwenden.
- Verwenden Sie keine übermäßige Kraft beim Anziehen oder Lösen der Schraube, um Beschädigungen zu vermeiden.
- Halten Sie den Arbeitsbereich sauber und frei von Hindernissen, um Stürze oder Unfälle zu vermeiden.

Anweisungen für Installation und Verwendung

1. Vorbereitung:

- Stellen Sie sicher, dass das Gewehr entladen ist, bevor Sie mit der Installation beginnen.
- Reinigen Sie den Bereich um die Hebelschraube, um Schmutz und Ablagerungen zu entfernen.

2. Installation:

- Entfernen Sie die originale Hebelschraube mit einem geeigneten Werkzeug.
- Setzen Sie die Schnellwechselschraube für Hebel Henry an der vorgesehenen Stelle ein.
- Ziehen Sie die Schraube mit dem empfohlenen Drehmoment an, um sicherzustellen, dass sie fest sitzt.

3. Verwendung:

- Überprüfen Sie vor jeder Verwendung die Festigkeit der Schraube.
- Achten Sie darauf, dass der Hebel ordnungsgemäß funktioniert und leicht zu bedienen ist.

4. Entfernung:

- Um die Schraube zu entfernen, wiederholen Sie die Schritte zur Installation in umgekehrter Reihenfolge.
- Lagern Sie die Schnellwechselschraube an einem sicheren Ort, wenn sie nicht in Gebrauch ist.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Vermeiden Sie die Entsorgung im normalen Hausmüll, wenn das Produkt als gefährlich eingestuft wird.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu Ihrem Produkt stehen Ihnen verschiedene Ressourcen zur Verfügung. Bitte konsultieren Sie die Website des Herstellers oder den Einzelhändler, bei dem Sie das Produkt gekauft haben, um weitere Informationen zu erhalten.

Bitte beachten Sie, dass die Einhaltung dieser Sicherheitshinweise dazu beiträgt, Verletzungen zu vermeiden und die Lebensdauer Ihres Produkts zu verlängern. Verwenden Sie die Schnellwechselschraube für Hebel Henry verantwortungsbewusst und sicher.

Safety Instruction Guide for the Henry Lever Quick Takedown Screw

Introduction

Thank you for choosing the Henry Lever Quick Takedown Screw. This product has been designed to enhance your shooting experience by allowing for easy lever removal and replacement. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the product is used only as intended.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not use the quick takedown screw if it is damaged or corroded.
- Ensure that the firearm is unloaded before attempting to install or remove the lever.
- Use appropriate tools to avoid damaging the screw or the firearm.
- Wear safety glasses to protect your eyes from any debris during installation.
- Do not attempt to modify the product in any way, as this may compromise safety.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded and safe to handle.
- Gather necessary tools: a screwdriver compatible with the screw head.

2. Installation

- Locate the original lever screw on your Henry firearm.
- Using the screwdriver, carefully remove the original lever screw.
- Take the Henry Lever Quick Takedown Screw and align it with the lever assembly.
- Insert the quick takedown screw and tighten it securely, but do not overtighten.

3. Usage

- To remove the lever, simply unscrew the quick takedown screw with your screwdriver.
- For cleaning or swapping levers, follow the same process in reverse.
- Regularly check the screw for tightness before use to ensure safety.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.
- Consider recycling the product if possible.

Contact Information for Further Support

For any questions or concerns regarding the Henry Lever Quick Takedown Screw, please refer to the manufacturer's contact information provided with your product packaging.

Thank you for your attention to these safety instructions. Enjoy using your Henry Lever Quick Takedown Screw responsibly and safely!