

Lever Quick Takedown Screw - Henry Lever Quick Takedown Screw - Black Nitride - 360 BUCKHAMMER

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting. Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting.

Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Attributes

- Name: Henry Lever Quick Takedown Screw - Black Nitride - 360 BUCKHAMMER
- Manufacturer: Ranger Point Precision
- Product no.: BRD261103
- Mfr. No.: 157
- Finish: Black Nitride
- Model: Henry
- Delivery weight: 0.5lb
- Shipping height: 150mm
- Shipping width: 200mm
- Shipping length: 25mm

Table of Contents

- Startpage
- Deutsch: Schnellwechselschraube für Hebel Henry Sicherheitshinweise
- English: Safety Instruction Guide for the Henry Lever Quick Takedown Screw

Schnellwechselschraube für Hebel Henry

Sicherheitshinweise

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der Schnellwechselschraube für Hebel Henry. Dieses Produkt wurde entwickelt, um Ihnen eine einfache Handhabung und Reinigung Ihres HenryGewehrs zu ermöglichen. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen.

Allgemeine Sicherheitshinweise

- Verwenden Sie die Schnellwechselschraube nur mit den angegebenen HenryModellen.
- Lagern Sie das Produkt an einem sicheren Ort, der für Kinder unzugänglich ist.
- Überprüfen Sie regelmäßig die Schraube auf Beschädigungen oder Abnutzung.
- Verwenden Sie keine beschädigte oder abgenutzte Schraube.
- Halten Sie sich an alle Anweisungen zur Installation und Verwendung.

Spezifische Sicherheitsvorkehrungen zur Verwendung

- Stellen Sie sicher, dass das Gewehr vor der Installation der Schnellwechselschraube entladen ist.
- Verwenden Sie beim Umgang mit Waffen stets Schutzausrüstung, insbesondere beim Schießen.
- Installieren Sie die Schraube nur, wenn Sie mit den grundlegenden Werkzeugen und Techniken vertraut sind.
- Bei Unsicherheiten wenden Sie sich an einen Fachmann oder einen qualifizierten Waffenmechaniker.
- Achten Sie darauf, dass die Schraube fest angezogen ist, um ein Lösen während der Verwendung zu verhindern.

Anweisungen zur Installation und Nutzung

1. Vorbereitung:

- Vergewissern Sie sich, dass das Gewehr entladen ist.
- Legen Sie alle benötigten Werkzeuge bereit (z.B. Schraubenschlüssel).

2. Installation:

- Entfernen Sie die originale Hebeleinschraube, indem Sie sie gegen den Uhrzeigersinn drehen.
- Setzen Sie die Schnellwechselschraube an die Stelle der originalen Schraube.
- Drehen Sie die Schnellwechselschraube im Uhrzeigersinn, bis sie fest sitzt.

3. Nutzung:

- Um den Hebel zu entfernen, lösen Sie die Schnellwechselschraube, indem Sie sie gegen den Uhrzeigersinn drehen.
- Reinigen Sie den Hebel und setzen Sie ihn bei Bedarf zurück.
- Achten Sie darauf, die Schraube nach dem Austausch des Hebels wieder festzuziehen.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für metallische Abfälle.
- Stellen Sie sicher, dass alle Teile sicher verpackt sind, um Verletzungen zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu diesem Produkt, wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Achten Sie darauf, alle Sicherheitsvorkehrungen zu befolgen und bei Bedarf professionelle Hilfe in Anspruch zu nehmen.

Schlussfolgerung

Die Schnellwechselschraube für Hebel Henry ist ein praktisches Zubehör, das Ihnen die Handhabung Ihres Gewehrs erleichtert. Indem Sie die oben genannten Sicherheitshinweise befolgen, stellen Sie sicher, dass Sie das Produkt sicher und effektiv nutzen können. Vielen Dank für Ihre Aufmerksamkeit und viel Spaß beim Schießen!

Safety Instruction Guide for the Henry Lever Quick Takedown Screw

Introduction

Thank you for purchasing the Henry Lever Quick Takedown Screw. This product is designed to facilitate the easy removal of your lever for cleaning and customization. Please read this safety instruction guide carefully to ensure safe and effective use.

General Safety Guidelines

- Ensure that the product is used in accordance with the instructions provided.
- Regularly inspect the product for any signs of wear or damage.
- Keep out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.
- Stay informed about product recalls via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before attempting to install or remove the lever screw.
- Use appropriate tools when installing or removing the screw to avoid injury.
- Do not modify the screw or the firearm in any way that is not recommended by the manufacturer.
- Wear safety glasses to protect your eyes from debris during installation.
- Do not force the screw if it does not fit; seek assistance if needed.

Instructions for Installation and Usage

1. Preparation

- Ensure that your firearm is completely unloaded and that the action is open.
- Gather necessary tools: a screwdriver compatible with the screw head.

2. Installation

- Locate the original lever screw on your Henry firearm.
- Using the screwdriver, carefully remove the original screw.
- Take the Henry Lever Quick Takedown Screw and align it with the screw hole.
- Insert the screw and tighten it securely but do not overtighten, as this may cause damage.

3. Usage

- To remove the lever for cleaning, simply unscrew the Quick Takedown Screw.
- Follow your firearm's cleaning instructions to ensure proper maintenance.
- To replace the lever, align it with the mounting point and secure it using the Quick Takedown Screw.

4. PostInstallation Check

- After installation, check that the lever operates smoothly.
- Ensure there are no loose parts or unusual noises during operation.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not throw the product in regular household waste.
- Consider recycling the material if possible.

Contact Information for Further Support

For any questions or concerns regarding the Henry Lever Quick Takedown Screw, please consult the manufacturer or authorized retailer for assistance. It is important to refer to the official guidelines and support channels for any issues related to product safety and maintenance.

By following these safety instructions, you can ensure the safe and effective use of your Henry Lever Quick Takedown Screw. Thank you for your attention to safety.