

EV30 Rucksack - Ash Green

[Emergency & Survival Gear](#) > [Backpacks & Bags](#)

Vorn hunting backpacks are used and praised by hunters around the world. With the weapon completely protected in the backpack, you can concentrate fully on the hunt.



The quick release system allows you to quickly and reliably grab the gun when you go to the ready.

The focus on details combined with high quality materials ensure that a Vorn backpack will sit comfortably on your back for many years!

The VORN EV30 with a volume of 30 liters is the smallest hunting backpack in the EV series. You have plenty of room for hunting equipment while enjoying the benefits of a compact and stylish hunting backpack.

- Patented QRR system for quick and reliable access to the hunting rifle.
- EV: outer and inner frame for optimal stability and carrying capacity.
- Spacious and adjustable gun compartment.
- Comfortable shoulder straps with VORN pin lock system for height adjustment.
- Strong hip belt with MOLLE attachment points.
- Compatible with hydration system (up to three liters).
- Side opening to entire main compartment
- Lid compartment with key hook
- Easy access padded front compartment
- Mesh pockets inside and outside
- Multiple handles, compression straps and attachment points
- Weapon cover for protection during transport
- Volume: 30 liters
- Weight: 2,45 kg

Additional information

- Fiber reinforced polymer frame
- Stainless steel trigger system
- Durable V-Tex, noiseless and water-resistant 3-layer fabric
- Water-repellent PU-coated YKK™ zippers, size #8
- Duraflex™ push-in closures
- High quality straps

Attributes

- Name: [VORN EV30 Rucksack - Ash Green](#)
- Manufacturer: [VORN](#)
- Product no.: BRD513083
- Mfr. No.: 0103
- Color: Ash Green
- Weight: 2,45 kg
- Delivery weight: 3kg
- EAN: 7090033551030

Table of Contents

- Startpage
- VORN EV30 Rucksack Safety Instructions
- About Us

VORN EV30 Rucksack Safety Instructions

Introduction

Thank you for choosing the VORN EV30 Rucksack in Ash Green. This product is designed for hunters who value both functionality and style. To ensure safe usage and longevity of your rucksack, please read and follow these safety instructions carefully.

General Safety Guidelines

- **Product Safety:** The VORN EV30 Rucksack is designed to be safe for use during hunting activities. Ensure you are familiar with all components before use.
- **Enhanced Recalls:** In the unlikely event of a product recall, you will be notified through standardized recall notices. Please follow the instructions provided in such cases.
- **Online Shopping:** If purchased online, ensure that the seller complies with EU safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Always supervise minors when using or handling the rucksack.
- **EU Contact Point:** For any safety inquiries, please refer to the contact information provided by the retailer or manufacturer.
- **Rapid Alerts:** Stay informed about product safety by checking the EU's Safety Gate platform for any updates regarding your product.

Specific Safety Precautions for Use

- **Check for Damage:** Before each use, inspect the rucksack for any signs of damage, such as tears or broken zippers. Do not use if damaged.
- **Load Capacity:** Do not exceed the rucksack's volume of 30 liters and weight capacity of 2.45 kg to avoid strain and ensure safe handling.
- **Weapon Safety:** Always ensure that your weapon is secured within the designated gun compartment and that it is unloaded when not in use.
- **Hydration System:** If using a hydration system, ensure it is properly installed and does not leak.
- **Weather Conditions:** Be aware of weather conditions. Avoid exposing the rucksack to extreme weather unless it is designed for such conditions.
- **Proper Use of Straps:** Adjust the shoulder straps and hip belt to fit securely and comfortably. Ensure all straps are fastened properly before moving.

Instructions for Installation and Usage

• Adjusting the Rucksack:

- Place the rucksack on a flat surface.
- Adjust the shoulder straps using the VORN pin lock system to fit your height and comfort.
- Secure the hip belt around your waist and tighten for stability.

• Loading the Rucksack:

- Open the main compartment and place your hunting equipment inside.
- Use the spacious gun compartment to securely store your weapon.
- Ensure that all items are properly packed and do not exceed the rucksack's capacity.

• Accessing Your Weapon:

- Use the patented QRR system to quickly access your weapon when needed.
- Practice using this system in a safe environment before heading out on a hunt.

- **Using the Padded Front Compartment:**

- Store items that require quick access in the padded front compartment.
- Ensure that this compartment is zipped securely after use.

- **Utilizing Additional Features:**

- Use the mesh pockets inside and outside the rucksack for smaller items.
- Attach additional gear using the MOLLE attachment points as needed.

Disposal Instructions

- **Environmental Responsibility:** When disposing of the VORN EV30 Rucksack, please follow local regulations for textile and plastic waste disposal.
- **Recycling:** If possible, recycle components such as fabric and zippers to minimize environmental impact.

Contact Information for Further Support

For further assistance or inquiries regarding safety, please refer to the contact information provided by the retailer or manufacturer. Always ensure you are using genuine VORN products for safety and reliability.

Thank you for your attention to these safety instructions. Enjoy your VORN EV30 Rucksack and have a safe and successful hunting experience!

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de