

EV45 Rucksack - Ash Green

[Emergency & Survival Gear](#) > [Backpacks & Bags](#)

Vorn hunting backpacks are used and praised by hunters around the world. With the weapon completely protected in the backpack, you can concentrate fully on the hunt. The quick release system allows you to quickly and reliably grab the gun when you go to the ready.



The focus on details combined with high quality materials ensure that a Vorn backpack will sit comfortably on your back for many years!

The VORN EV45 with a volume of 45 liters is the largest hunting backpack in the EV series. You have plenty of space and easy access to your hunting equipment.

Patented QRR system for quick access to your hunting rifle.

EV: outer and inner frame for optimal stability and carrying capacity.

Spacious and adjustable gun compartment.

Comfortable shoulder straps with VORN pin lock system for height adjustment.

Strong hip belt with MOLLE attachment points.

Compatible with hydration system (up to three liters).

Backpack lid with three individual compartments and key hooks

Side opening to main compartment

Easy access padded front compartment

Mesh pockets inside and outside

Multiple handles, compression straps and attachment points

Weapon cover for protection during transport

Volume: 45 liters

Weight: 2,75 kg

Additional information

- Fiber reinforced polymer frame
- Stainless steel trigger system
- Durable V-Tex, noiseless and water-resistant 3-layer fabric
- Water repellent PU coated YKK™ zippers, size #8
- Duraflex™ push-in closures
- High quality straps

Attributes

- Name: [VORN EV45 Rucksack - Ash Green](#)
- Manufacturer: [VORN](#)
- Product no.: BRD513084
- Mfr. No.: 0104
- Color: Ash Green
- Weight: 2,75 kg
- Delivery weight: 3.1kg
- EAN/UPC: 70900333551047

Table of Contents

- Startpage
- VORN EV45 Rucksack Safety Instruction Guide
- About Us

VORN EV45 Rucksack Safety Instruction Guide

Introduction

Thank you for choosing the VORN EV45 Rucksack Ash Green. This guide provides essential safety instructions to ensure the safe use of your backpack, in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure the rucksack is suitable for your intended use and that you are familiar with its features.
- Inspect the rucksack for any damage or defects before each use.
- Store the rucksack in a dry, cool place when not in use to prevent damage from moisture or extreme temperatures.
- Keep the rucksack away from sharp objects that could cause punctures or tears.
- Avoid overloading the rucksack beyond its specified volume and weight capacity.
- Ensure that all straps and compartments are securely fastened before use.
- Be cautious when using the rucksack in adverse weather conditions.

Specific Safety Precautions for Use

- Always use the shoulder straps and hip belt to distribute weight evenly and reduce strain on your back.
- Adjust the shoulder straps and hip belt to fit snugly but comfortably.
- When accessing your hunting equipment, ensure that the rucksack is securely positioned to prevent it from falling or shifting.
- Be mindful of your surroundings when using the rucksack, especially in crowded or uneven terrain.
- If using the hydration system, ensure that it is properly secured to prevent leaks.
- Keep the weapon cover securely in place during transport to avoid accidental discharge or injury.

Instructions for Installation and Usage

1. Adjusting the Straps:

- Unclip the shoulder straps and hip belt.
- Put the rucksack on your back and adjust the shoulder straps for a comfortable fit.
- Secure the hip belt around your waist and adjust for snugness.

2. Using the QRR System:

- Locate the quick release mechanism.
- Practice opening and closing the system to ensure you can operate it efficiently when needed.

3. Accessing the Main Compartment:

- Use the side opening to access the main compartment quickly.
- Ensure the zippers are fully closed after accessing your equipment.

4. Using the Padded Front Compartment:

- Store items that you need quick access to in the padded front compartment.
- Ensure that the compartment is securely zipped after use.

5. Hydration System Setup:

- Insert the hydration bladder into the designated compartment.

- Connect the drinking tube and ensure it is accessible.

6. Packing the Rucksack:

- Distribute weight evenly throughout the compartments.
- Use compression straps to secure your load.

Disposal Instructions

- When the rucksack reaches the end of its life cycle, dispose of it responsibly.
- Check local regulations for proper disposal methods for polymer and fabric materials.
- Recycle components where possible to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or assistance regarding the VORN EV45 Rucksack, please contact the manufacturer or your local distributor. It is essential to have a point of contact for reporting any safety concerns or product issues.

Conclusion

Your safety is our priority. By following these guidelines, you can ensure a safe and enjoyable experience with your VORN EV45 Rucksack. Always stay informed about product recalls and safety updates through the EU's Safety Gate platform. Thank you for choosing VORN!

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de