

Snow Cover - White/Blaze

Practical snow cover for backpacks with orange panel in front for better visibility.

Perfect if you want to camouflage yourself when hunting in the snow.

Can be folded into the rain cover if desired.

Additional information

Size: 20 - 45 liters.

Attributes

- Name: Vorn Snow Cover - White/Blaze
- Manufacturer: VORN
- Product no.: BRD513088
- Mfr. No.: 0538
- Color: White/Blaze
- Delivery weight: 0.3kg
- EAN: 7090033550538

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die Vorn Schneehülle
- English: Vorn Snow Cover Safety Instructions

Sicherheitshinweise für die Vorn Schneehülle

Einführung

Vielen Dank, dass Sie sich für die Vorn Schneehülle entschieden haben. Diese praktische Schneehülle wurde entwickelt, um Ihre Rucksäcke beim Jagen im Schnee zu tarnen und gleichzeitig die Sichtbarkeit durch das orangefarbene Panel zu erhöhen. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere und effektive Nutzung des Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass die Schneehülle für den vorgesehenen Zweck verwendet wird.
- Überprüfen Sie die Schneehülle vor jedem Gebrauch auf Schäden oder Abnutzung.
- Halten Sie die Schneehülle von Feuer und extremen Temperaturen fern.
- Lagern Sie die Schneehülle an einem trockenen Ort, um Schimmelbildung zu vermeiden.
- Achten Sie darauf, dass Kinder die Schneehülle nicht als Spielzeug verwenden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Vermeiden Sie es, die Schneehülle in der Nähe von scharfen Gegenständen zu verwenden, um Beschädigungen zu verhindern.
- Tragen Sie die Schneehülle nur auf Rucksäcken, die in der angegebenen Größe von 20 – 45 Litern sind.
- Wenn Sie die Schneehülle in die Regenhülle falten, stellen Sie sicher, dass sie vollständig trocken ist, um Schimmelbildung zu vermeiden.
- Verwenden Sie die Schneehülle nicht während starker Winde oder ungünstiger Wetterbedingungen, die Ihre Sicherheit gefährden könnten.

Anweisungen zur Installation und Nutzung

1. Vorbereitung:

- Stellen Sie sicher, dass Ihr Rucksack sauber und trocken ist.

2. Anbringen der Schneehülle:

- Ziehen Sie die Schneehülle über den Rucksack und stellen Sie sicher, dass sie gut sitzt.
- Achten Sie darauf, dass das orangefarbene Panel nach vorne zeigt, um die Sichtbarkeit zu maximieren.

3. Falten in die Regenhülle:

- Um die Schneehülle in die Regenhülle zu falten, entfernen Sie sie vorsichtig vom Rucksack.
- Falten Sie die Schneehülle gemäß den Faltlinien, um sie kompakt zu verstauen.

4. Überprüfung:

- Überprüfen Sie nach der Installation, ob die Schneehülle richtig sitzt und keine losen Teile hat.

Entsorgungsanweisungen

- Entsorgen Sie die Schneehülle gemäß den lokalen Vorschriften für Kunststoffabfälle.
- Wenn die Schneehülle beschädigt oder nicht mehr verwendbar ist, stellen Sie sicher, dass sie umweltgerecht entsorgt wird.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Informationen zur Sicherheit des Produkts wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Achten Sie darauf, dass alle Produkte mit einem EU-basierten Kontaktpunkt versehen sind, um Sicherheitsanfragen zu bearbeiten.

Schlussfolgerung

Die Vorn Schneehülle ist ein nützliches Produkt, das Ihnen hilft, beim Jagen im Schnee sicher und sichtbar zu bleiben. Beachten Sie bitte die oben genannten Sicherheitsrichtlinien und verwenden Sie das Produkt verantwortungsvoll. Bei weiteren Fragen oder Bedenken wenden Sie sich bitte an den entsprechenden Ansprechpartner.

Vorn Snow Cover Safety Instructions

Introduction

Thank you for choosing the Vorn Snow Cover. This product is designed to provide practical protection for your backpack during snowy conditions while enhancing visibility with its distinctive orange panel. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the snow cover is suitable for your backpack size (20-45 liters).
- Always check the snow cover for any signs of damage before use.
- Do not use the snow cover in conditions for which it is not intended, such as heavy rain or extreme wind.
- Keep the snow cover out of reach of children when not in use.
- If you notice any defects or malfunctions, discontinue use immediately and report the issue.

Specific Safety Precautions for Use

- When using the snow cover, ensure it is securely fastened to your backpack to prevent it from blowing away.
- Avoid using the snow cover in low visibility conditions where it may not provide adequate safety.
- Be cautious when moving through snow-covered areas to avoid slips and falls.
- If using the cover for hunting purposes, ensure that you are in compliance with local hunting regulations and safety practices.

Instructions for Installation and Usage

1. Preparing the Snow Cover:

- Unfold the snow cover and lay it flat.
- Ensure that the orange panel is facing outward for maximum visibility.

2. Attaching the Snow Cover:

- Place the snow cover over your backpack, ensuring it fits snugly.
- Use the built-in straps or fasteners to secure the cover to the backpack.
- Adjust the straps as necessary to ensure a tight fit.

3. Using the Snow Cover:

- When in use, periodically check that the cover remains securely fastened.
- If desired, the snow cover can be folded into the rain cover for additional protection.

4. Removing the Snow Cover:

- To remove, simply unfasten the straps and lift the cover off.
- Fold the cover neatly for storage when not in use.

Disposal Instructions

- Dispose of the snow cover responsibly. If it is no longer usable, consider recycling it if possible.
- Follow local regulations for disposal of textile materials.

Contact Information for Further Support

For any safety inquiries or further assistance, please reach out to the designated EU contact point for consumer safety issues.

Thank you for your attention to these safety guidelines. Enjoy your Vorn Snow Cover and stay safe!