

DAA Magnetic Magazine Pouch

Product Update: DAA Magnetic Magazine Pouch with "Clip On" Base Pad

Brief Description: The DAA Magnetic Magazine Pouch just got even better! We're thrilled to announce that all DAA Magnetic pouches now come equipped with the innovative "Clip On" base pad. This revolutionary addition significantly reduces belt bulk, occupying less space and minimizing the gap between your inner and outer belts.



Key Features: With this base pad, you can securely mount your magnetic pouch close to other pouches without concern about the outer belt losing grip on the inner—a must-have for stages requiring quick magazine pickups. The custom-made magnetic mag holder allows you to slap your extra magazine onto your belt as fast as picking it up from the table, eliminating fumbling and saving precious time during reloads!

The magnet boasts a diameter of almost 50mm and a thickness of over 10mm, providing a pulling power exceeding 100kg! This ensures a secure hold on your loaded magazine even during dynamic movements. Its smooth surface enables a rapid upward slide for a fast reload, making it ideal for efficient reloading.

Warning: Keep the magnet away from credit cards and electronic equipment due to its powerful magnetic field.

Upgrade your gear with the DAA Magnetic Magazine Pouch featuring the "Clip On" base pad—efficiency and speed redefined for your shooting experience.

Attributes

- Name: DAA Magnetic Magazine Pouch
- Manufacturer: DAA Double Alpha Academy
- Product no.: BRD523005
- Mfr. No.: 100474
- Delivery weight: 1kg

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitsanleitung für die DAA Magnetische Magazinhaltung](#)
- [English: DAA Magnetic Magazine Pouch Safety Instruction Guide](#)

Sicherheitsanleitung für die DAA Magnetische Magazinhalterung

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der DAA Magnetischen Magazinhalterung mit "Clip On" Basisplatte! Diese Halterung wurde entwickelt, um Ihnen ein sicheres und effizientes Schießerlebnis zu bieten. Bitte lesen Sie die folgenden Sicherheitsanweisungen sorgfältig durch, um eine sichere Verwendung des Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass die Halterung nur für den vorgesehenen Zweck verwendet wird.
- Lagern Sie die Halterung an einem trockenen Ort, fern von direkter Sonneneinstrahlung und extremen Temperaturen.
- Überprüfen Sie die Halterung regelmäßig auf Beschädigungen oder Abnutzungserscheinungen.
- Halten Sie den Magneten von Kreditkarten und elektronischen Geräten fern, um mögliche Schäden zu vermeiden.
- Bewahren Sie das Produkt außerhalb der Reichweite von Kindern auf.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie die Halterung nur mit kompatiblen Magazinen.
- Achten Sie darauf, dass der Magnet ordnungsgemäß befestigt ist, bevor Sie das Magazin anbringen.
- Vermeiden Sie es, die Halterung während dynamischer Bewegungen zu berühren, um Verletzungen zu vermeiden.
- Tragen Sie beim Schießen geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Anweisungen für Installation und Verwendung

Installation

1. **Vorbereitung:** Stellen Sie sicher, dass Ihr Gürtel und die Halterung sauber und trocken sind.
2. **Befestigung:** Platzieren Sie die "Clip On" Basisplatte an der gewünschten Stelle auf Ihrem Gürtel.
3. **Sicherung:** Drücken Sie die Basisplatte fest an, bis sie einrastet. Überprüfen Sie, ob die Halterung sicher sitzt.

Verwendung

1. **Magazin einlegen:** Nehmen Sie Ihr Magazin und halten Sie es in der Nähe der Halterung.
2. **Magnet nutzen:** Bringen Sie das Magazin in die Nähe des Magneten, um es sicher zu befestigen.
3. **Entfernen:** Um das Magazin zu entfernen, ziehen Sie es einfach vom Magneten weg, ohne zu ruckeln.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektroschrott.
- Trennen Sie den Magneten von anderen Materialien, falls möglich, um eine ordnungsgemäße Entsorgung zu gewährleisten.

Kontaktinformationen für weitere Unterstützung

Bitte wenden Sie sich an den Hersteller oder den Verkäufer für weitere Informationen oder Unterstützung. Halten Sie die Produktverpackung und Rechnungsdetails bereit, um eine schnelle Bearbeitung zu gewährleisten.

Wir hoffen, dass Sie mit der DAA Magnetischen Magazinalterung viel Freude haben und wünschen Ihnen ein sicheres Schießergebnis!

DAA Magnetic Magazine Pouch Safety Instruction Guide

Introduction

Thank you for choosing the DAA Magnetic Magazine Pouch with "Clip On" Base Pad. This guide provides essential safety instructions to ensure safe and effective use of your product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the pouch is only used for its intended purpose of holding and securing magazines.
- Keep the pouch away from children and vulnerable individuals to prevent accidental injuries.
- Regularly inspect the pouch for any signs of wear or damage. Do not use if damaged.
- Always follow the installation and usage instructions provided in this guide.
- Be aware of your surroundings when using the pouch, especially in dynamic environments.

Specific Safety Precautions for Use

- **Magnet Safety:**
 - Keep the magnetic pouch away from credit cards, electronic devices, and sensitive equipment due to its powerful magnetic field.
 - Avoid placing the pouch near metallic objects that could interfere with its magnetic function.
- **Belt Compatibility:**
 - Ensure that your belt is compatible with the "Clip On" base pad to avoid detachment during use.
 - Do not overload the pouch beyond its intended capacity to maintain secure attachment and functionality.
- **Dynamic Movements:**
 - Use caution during dynamic movements to ensure the pouch remains secure and does not pose a risk of dropping the magazine.
- **Environment:**
 - Avoid using the pouch in extreme weather conditions that may affect its performance or safety.

Instructions for Installation and Usage

- **Installation:**
 1. Attach the "Clip On" base pad securely to your belt, ensuring it is firmly in place.
 2. Align the magnetic magazine pouch with the base pad and press down until you hear a click, indicating it is securely attached.
 3. Ensure that the pouch is positioned for easy access to magazines without obstruction.
- **Usage:**
 1. To insert a magazine, simply align it with the magnetic holder and allow it to snap into place.
 2. For removal, grasp the magazine and pull it away from the pouch with a smooth motion.
 3. Practice reloading with the pouch in a safe environment to become familiar with its operation.

Disposal Instructions

- Dispose of the DAA Magnetic Magazine Pouch in accordance with local regulations for electronic and magnetic waste.
- Do not dispose of the pouch in regular household waste.

- If the pouch is no longer functional or safe to use, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

- For any safety inquiries or additional support regarding the DAA Magnetic Magazine Pouch, please refer to the manufacturer's contact information provided on the product packaging or visit the manufacturer's website.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the DAA Magnetic Magazine Pouch!