BUSHING FULL LENGTH DIES - L.E. WILSON 338 NORMA MAG FULL LENGTH SIZING DIE

Reloading > Reloading Dies > Rifle Dies

The Wilson Bushing Type Full Length Sizing Die. This die will allow you to size the case neck to your desired neck tension along with sizing down the rest of the case body at the same time. Die includes an adjustable depth decapping rod. An extra Decapping Punch is included. These dies do not contain an expander. Made of High Quality Heat Treated Steel. These Full Length Bushing dies mimic the neck sizing of Wilsons' neck sizing dies and are designed to leave 3/16" at the bottom of the case neck unsized, a practice many shooters prefer and find to be more accurate than sizing the full neck. Mad from High Quality Material - Hardened to L.E. Wilson Specifications Harder than a Grade 8 Bolt Interchangeable Bushings Standard 7/8ths Reloading Press Sizes Shoulder and Body Dimensions Stainless Parts for a Long Lasting Finish Durable and Accurate L.E. Wilson manufactured lock nut - thickness is .225" from inside to outermost edge .270" for height and 1.250" total width OD. Neck Bushing sold separately, we suggest using LE Wilson Neck bushings but Redding bushings will also fit.



Attributes

- Name: L.E. WILSON 338 NORMA MAG FULL LENGTH SIZING DIE
- Manufacturer: L.E. WILSON
- Product no.: 430116137
- Mfr. No.: FLD-338NM
- Cartridge: 338 Norma Mag
- Die Style: Full Length Sizing Die
- Delivery weight: 0.277kg
- Shipping height: 51mm
- Shipping width: 51mm
- Shipping length: 152mm
- UPC: 815145026507

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for BUSHING FULL LENGTH DIES L.E. WILSON 338 NORMA MAG FULL LENGTH SIZING DIE
- About Us

Safety Instruction Guide for BUSHING FULL LENGTH DIES L.E. WILSON 338 NORMA MAG FULL LENGTH SIZING DIE

Introduction

Thank you for choosing the Bushing Full Length Dies by L.E. Wilson. This product is designed to provide you with precise case sizing for your reloading needs. While using this tool, it is crucial to follow safety guidelines to ensure safe and effective operation. This guide provides essential safety instructions and operational guidance in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure you read and understand all instructions before using the die.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the workspace clean and organized to prevent accidents.
- Use the die only for its intended purpose as specified in this guide.
- Store the die in a safe place, out of reach of children and vulnerable individuals.
- Regularly inspect the die for wear or damage before use, and do not use it if any parts are damaged.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Handle the die with care to avoid injury from sharp edges or moving parts.
- Ensure the reloading press is securely mounted and stable before operation.
- Do not exceed the recommended load limits for the die and your reloading press.
- When adjusting the die, ensure that the press is not under load to prevent accidental release or injury.
- Be cautious of hot surfaces and materials, especially if using the die in conjunction with heattreated cases.
- Do not modify the die or use it in any manner other than what is specified in this guide.

Instructions for Installation and Usage

1. **Installation:**
    - Ensure that your reloading press is clean and free of debris.
    - Thread the Bushing Full Length Sizing Die into the reloading press using standard 7/8ths threads.
    - Tighten the die securely, ensuring there is no movement during operation.
    - Insert the adjustable depth decapping rod into the die and adjust to the desired depth.
2. **Usage:**
    - Place a case into the shell holder of the reloading press.
    - Raise the ram to bring the case into contact with the die.
    - Apply steady pressure to size the case neck and body simultaneously.
    - After sizing, lower the ram and remove the case from the shell holder.
    - Inspect the sized case for proper dimensions and quality.
    - Repeat the process as necessary for additional cases.
3. **Neck Bushing:**

    - Note that neck bushings are sold separately. It is recommended to use L.E. Wilson Neck bushings for optimal performance, although Redding bushings may also fit.
    - Ensure the neck bushing is properly seated in the die before use.

Disposal Instructions

- Dispose of any damaged or unusable parts in accordance with local regulations.
- Do not throw the die in regular waste; check for recycling options for metal components.
- Ensure that all packaging materials are disposed of responsibly.

Contact Information for Further Support

For any inquiries or further assistance, please refer to the official L.E. Wilson website or contact your local distributor. Always ensure that you have the latest information regarding safety recalls or product updates.

By following these safety instructions, you can ensure a safer and more effective reloading experience with your Bushing Full Length Dies L.E. Wilson 338 Norma Mag Full Length Sizing Die. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk