

1911 45 ACP FLAT WIRE RECOIL SPRING - ED BROWN 1911 GOVERNMENT 45 ACP 18# FLAT WIRE RECOIL SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

The flat wire spring for 1911 handguns is a must for any handgun enthusiast or full time shooter. Manufactured from Chrome Silicon alloy to maximize spring longevity and load. The longest lasting handgun recoil spring made - up to ten times greater service life than a conventional coil spring. Other benefits of switching from conventional round wire to flatwire include improved cycling and more tolerant to a wider variety of loads. Intended for use with our flat wire guide rod system. Recommended spring replacement at 30,000-40,000 rounds. Will not work with a standard recoil spring guide and plug, only the flat wire guide rod and plug.



Attributes

- Name: [ED BROWN 1911 GOVERNMENT 45 ACP 18# FLAT WIRE RECOIL SPRING](#)
- Manufacturer: [ED BROWN](#)
- Product no.: 430109543
- Mfr. No.: 918-FW-45G
- Model: Government
- Pounds: 18 lbs
- Weapon type: 1911
- Delivery weight: 0.023kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 229mm
- UPC: 800732918020

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for 1911 45 ACP Flat Wire Recoil Spring](#)
- [About Us](#)

Safety Instruction Guide for 1911 45 ACP Flat Wire Recoil Spring

Introduction

Thank you for choosing the 1911 45 ACP Flat Wire Recoil Spring by ED BROWN. This product is designed to enhance the performance and longevity of your 1911 handgun. Please read this safety instruction guide carefully to ensure safe and effective use of the recoil spring.

General Safety Guidelines

- Ensure that you are familiar with the operation of your handgun before using the recoil spring.
- Always handle firearms with care and follow all safety protocols.
- Store the recoil spring in a cool, dry place away from direct sunlight and moisture.
- Keep the recoil spring and all firearm components out of reach of children and unauthorized users.
- Regularly inspect the recoil spring for signs of wear or damage before each use.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the recoil spring with the specified flat wire guide rod system.
- Do not attempt to use the recoil spring with standard recoil spring guides and plugs.
- Recommended spring replacement should occur after firing 30,000-40,000 rounds.
- Ensure that the firearm is unloaded before installing or replacing the recoil spring.
- Avoid using the recoil spring with loads that exceed the manufacturer's specifications.
- If you experience any malfunctions or unusual performance, discontinue use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. **Ensure Safety:** Before starting, make sure the firearm is unloaded and pointed in a safe direction.
2. **Remove the Old Spring:**
 - Disassemble your firearm according to the manufacturer's instructions.
 - Carefully remove the old recoil spring from the guide rod.
3. **Install the New Spring:**
 - Take the new flat wire recoil spring and place it onto the guide rod.
 - Ensure that it is seated properly and securely.
4. **Reassemble the Firearm:**
 - Follow the manufacturer's instructions to reassemble your firearm.
 - Doublecheck that all components are properly aligned and secured.
5. **Test Functionality:**
 - Conduct a function check with the firearm in a safe environment.
 - Ensure that the firearm cycles properly with the new recoil spring.
6. **Regular Maintenance:**
 - Clean and lubricate the recoil spring and guide rod as per your firearm's maintenance schedule.
 - Regularly inspect the recoil spring for wear and replace as necessary.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations.
- Do not dispose of the recoil spring in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any questions or concerns regarding the 1911 45 ACP Flat Wire Recoil Spring, please consult your local dealer or a qualified gunsmith. It is important to seek professional assistance if you are unsure about any aspect of the installation or use of this product.

Thank you for your attention to these safety guidelines. Enjoy your enhanced shooting experience with the 1911 45 ACP Flat Wire Recoil Spring.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk